



PACKAGING CONSULTANTS
INTERNATIONAL

Silicone Sampling Protocol

Sample Submission:

- Minimum 200 mL of silicone in a sterile, leak and shatter proof vial/bottle.
- Each sample should be placed in a plastic storage bag (ex. Ziploc).
- Clear identification of each sample on the outside of the storage bag.
- Sample should be wrapped in a protective material (ex. bubble wrap) that will prevent the vial from cracking & leaking during transportation.
- Lab should receive notice of impending water sample submission at least 24 hours in advance
- Sample should be kept on ice packs when shipped to lab if possible.
- Sample should be sent via an overnight courier to test within 24 hours of sampling.
- Sample should be clearly labeled “Silicone Sample” on the outside of shipping box.
- Samples should not be shipped on Friday for weekend delivery.

**1101 State Fair Boulevard
Syracuse, New York 13209**

Tel: (315) 468-6234 Fax: (315) 468-6235

www.pcilabs.com · kate@pcilabs.com · tim@pcilabs.com · patrick@pcilabs.com